



Scale: NONE

NOTES:

1. Be sure that the substrates are clean and free of loose or flaking materials prior to application.
2. Apply the first application of #800 with a brush or trowel extending 2" beyond the polyester application to follow.
3. Immediately embed the polyester fabric into the wet material ensuring that the fabric is free of all air pockets and wrinkles.
4. Apply the second application of #800 making sure that the polyester is evenly covered and that the edges of the detail are properly feathered.
5. Once cured, repeat steps 2-4 as described above.
6. Do not apply #800 in a thickness greater than 3/16" (both coats) as this may cause improper curing. If thicker applications are required, allow to cure and apply additional coat.
7. Best results are achieved if #800 is coated with ElastaHyde following full cure.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

5-Course Detail Application

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

DP-5CRS-1