



Scale: NONE

NOTES:

1. Clean the wall and flashing of dirt and remove any loose or flaking existing material. Wire brushing may be necessary to remove any rust that may be present. Should there be rust present, priming with #900R MTL + Rust Primer is recommended.
2. The counter flashing to wall transition is detailed with #800 and polyester membrane per detail DP-3CRS. Ensure that the detail work extends a minimum of 2" onto either substrate. The polyester width may vary based on the existing condition.
3. Encapsulate the detail work with the applications of ElastaHyde following full cure for best results.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

Counter Flashing Maintenance

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

RM-CF1