



Scale: NONE

NOTES:

1. Once the membrane system has been installed the penetration detailing may be applied.
2. Remove any loose or flaking materials from the penetration assembly and ensure that there is no residual oils present on the new membrane.
3. Once the area has been properly prepared and primed where necessary, detail the pipe enclosure with #800 and polyester membrane per detail DP-3CRS.
4. When detailing be sure to extend material onto the vent flange and extend a minimum of 6" onto the new membrane.
5. Encapsulate the detail work with the applications of ElastaHyde following full cure for best results.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

Multiple Pipe Enclosure

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

SD-P2