



NOTES:

1. Once the membrane system has been installed per the membrane specification the membrane termination may be addressed.
2. Remove any loose or flaking materials from the drip edge and ensure that there is no residual oils present on the new membrane.
3. Detail the termination to flashing transition with a 4" application of #800 and polyester membrane per detail DP-3CRS.
4. When detailing be sure to extend the polyester a minimum of 2" onto both substrates feathering the edges.
5. Encapsulate the detail work with the applications of ElastaHyde following full cure for best results.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

Roof Edge-Drip Edge

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

SD-RE1