



Scale: NONE

NOTES:

1. Prior to the field membrane installation the cant strip detail at walls and curbs must be completed.
2. Ensure that the substrates are clean, free of loose or flaking materials, and field repairs and preparations are fully cured prior to application.
3. Apply the application of #298 Emulsion by sprayer, roller or brush at a rate of 6 gallons per square or as specified, extending 2" beyond the polyester application to follow, centered over the horizontal to vertical transition at the cant strip.
4. Immediately embed the 12" polyester fabric, via light broom, into the wet material ensuring that the fabric is free of all air pockets and wrinkles. Excess emulsion at the edges may require feathering of the wet material.
5. Once the cant strip detail is complete the base flashing and field membrane installations may be performed. (Refer to the System Details for membrane termination and penetration detailing requirements.)

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

System Base Flashing

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

SD-SBF1