



Scale: NONE

NOTES:

1. Remove any loose or flaking materials from the penetration assembly and the existing membrane.
2. Once the area has been properly prepped and primed where necessary, detail the vent flashing with #800 and polyester membrane per detail DP-3CRS.
3. When detailing be sure to extend material onto the vent flange and extend a minimum of 6" onto the existing membrane.
4. Encapsulate the detail work with the applications of Elastahyde following full cure for best results.
5. Should the T-Top Flashing be placed at the time of the detailing, set the flange into an application of #8000 All Weather Elastic Cement.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

T-Top Maintenance

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

RM-TT1