



Scale: NONE

NOTES:

1. Clean the scupper assembly of debris and dirt and remove any loose or flaking existing material. Wire brushing may be necessary to remove any rust that may be present. Should there be rust present, priming with #900R MTL + Rust Primer is recommended.
2. Once the area has been properly prepared and primed, detail the scupper with #800 and polyester membrane per detail DP-5CRS.
3. When detailing be sure to extend material into the scupper assembly and extend a minimum of 6" onto the existing membrane.
4. Best results are achieved if #800 is coated with ElastaHyde following full cure.

**This Detail is intended for conceptual purposes only.*



DETAIL DESCRIPTION:

Scupper

ISSUE DATE:

12/29/2014

DETAIL NUMBER:

SD-D3