



**NOTES:**

1. Remove the existing drain cover and clamping ring from the drain assembly.
2. Clean the drain assembly of debris and dirt and remove any loose or flaking existing material. Wire brushing may be necessary to remove any rust that may be present. Should there be rust present, priming with #900R MTL + Rust Primer is recommended.
3. Once the area has been properly prepared and primed, detail the drain with #800 and polyester membrane per detail DP-5CRS.
4. When detailing be sure to extend material into the drain assembly and extend a minimum of 6" onto the existing membrane or beyond drain sump.
5. Pay close attention to the clamping prongs on the flange making sure that they are honored and not excessively coated with materials. Doing so will ensure simple reattachment of the drain ring and cover once detailing is complete.
6. Best results are achieved if #800 is coated with ElastaHyde following full cure.

*\*This Detail is intended for conceptual purposes only.*



**DETAIL DESCRIPTION:**

**Roof Drain-Clamping Ring**

**ISSUE DATE:**

12/29/2014

**DETAIL NUMBER:**

SD-D1